

M3 SL20K Series

Accessory Specs sheet

Version 1.0 © 2024

Korea Headquarter Seoul, Korea | sales@m3mobile.co.kr | +82-(0)2-574-0037

Europe Headquarter Germany, Frankfurt | sales_eu@m3mobile.net | +49-(0)-6190-8021829

www.m3mobile.net

Revision

Release date of version 1.0: Dec. 2024

- Initial distribution

Table of Contents

Contents

| | | |
|-------|--|---|
| 1. | 1-Slot Charging Cradle..... | 5 |
| 1.1 | Specification..... | 5 |
| 1.2 | Use Case..... | 5 |
| 1.2.1 | Fast Charging..... | 5 |
| 1.2.2 | Easy to use..... | 5 |
| 2.1 | Specification..... | 6 |
| 2.2 | Use Case..... | 6 |
| 2.2.1 | Fast Charging..... | 6 |
| 2.2.2 | USB Sync..... | 6 |
| 2.2.3 | Easy to use..... | 6 |
| 3. | 8-Slot Charging Cradle..... | 7 |
| 3.1 | Specification..... | 7 |
| 3.2 | Use Case..... | 7 |
| 3.2.1 | Fast Charging..... | 7 |
| 3.2.2 | Easy to use..... | 7 |
| 4. | 8-Slot Charging & Ethernet Cradle..... | 8 |
| 4.1 | Specification..... | 8 |
| 4.2 | Use Case..... | 8 |
| 4.2.1 | Fast Charging..... | 8 |
| 4.2.2 | Ethernet Connection and USB Sync..... | 8 |
| 4.2.3 | Easy to use..... | 8 |
| 5. | Trigger Handle..... | 9 |

| | | |
|--------------|---------------------------------|----|
| 5.1 | Specification | 9 |
| 5.2 | Use Case | 9 |
| 5.2.1 | Formal environment | 9 |
| 5.2.2 | How to combine | 9 |
| 6. | Hand Strap | 10 |
| 6.1 | Use Case | 10 |
| 6.1.1 | How to combine | 10 |
| 7. | Trigger Handle | 11 |
| 7.1 | Contacts | 11 |

1. 1-Slot Charging Cradle

- Application Devices: SL20K Series



1.1 Specification

| Model | 1-Slot Charging Cradle |
|---------------|------------------------|
| I/O | DC |
| Input | DC 5V / 3A |
| Dimension | 112x156x77 |
| Weight | 290g |
| Compatibility | SL20K Series |

1.2 Use Case

1.2.1 Fast Charging

Charging in about 4 Hours (20 minutes deviation)

1.2.2 Easy to use

i. Connect SL20K to the Charging Cradle → ii. Charging

- 2-Slot Charging & USB Cradle
- Application Devices: SL20K Series



2.1 Specification

| Model | 2-Slot Ethernet Cradle |
|---------------|------------------------|
| I/O | DC / USB-C type Client |
| Input | DC 5V / 3A |
| Dimension | 112x156x77 |
| Weight | 290g |
| Compatibility | SL20K Series |

2.2 Use Case

2.2.1 Fast Charging

Charging in about 4 Hours (20 minutes deviation)

2.2.2 USB Sync

| USB Sync |
|-----------------|
| Data connection |

2.2.3 Easy to use

i. Connect SL20K to the Cradle → ii. Charging and Data Connection.

3. 8-Slot Charging Cradle

- Application Devices: SL20K Series



3.1 Specification

| Model | 8-Slot Charging Cradle |
|---------------|------------------------|
| I/O | DIN4 |
| Input | DC 12V / 7A |
| Dimension | 450x156x87.9 |
| Weight | 710g |
| Compatibility | SL20K Series |

3.2 Use Case

3.2.1 Fast Charging

Charging in about 4 Hours (30 minutes deviation)

3.2.2 Easy to use

i. Connect SL20K to the Charging Cradle → ii. Charging

4. 8-Slot Charging & Ethernet Cradle

- Application Devices: SL20K Series



4.1 Specification

| Model | 5-Slot Ethernet Cradle |
|---------------|------------------------|
| I/O | DIN4 / RJ-45 |
| Input | DC 12V / 7A |
| Dimension | 450x156x87.9 |
| Weight | 720g |
| Compatibility | SL20K Series |

4.2 Use Case

4.2.1 Fast Charging

Charging in about 4 Hours (30 minutes deviation)

4.2.2 Ethernet Connection and USB Sync

Ethernet Connection

You can use Local Area Network Via SL20K Series with Ethernet Cradle

4.2.3 Easy to use

i. Connect SL20K to the Ethernet Cradle → ii. Charging or Data Connection.

5. Trigger Handle

- Application Devices: SL20K Series



5.1 Specification

| Model | Trigger Handle |
|---------------|----------------|
| I/O | N/A |
| Input | N/A |
| Dimension | 73x130x165.2 |
| Weight | 120g |
| Compatibility | SL20K Series |

5.2 Use Case

5.2.1 Formal environment

The trigger handle has essential functions properly in industrial environments.

The design is ergonomically made by measurement in mechanical team.

5.2.2 How to combine

1. Loosen the four screws on the bottom of the device.
2. Insert the Trigger Handle into the shaft at the bottom of the camera.
3. Assemble with 4 screws supplied with the Trigger Handle.
4. Installation of Trigger Handle.

6. Hand Strap

- Application Devices: SL20K Series



6.1 Use Case

6.1.1 How to combine



1. Insert the strap into the top and bottom rings of the device.



2. Insert the arrow-shaped part of the strap into the slot below the strap attachment point.



3. Insert the arrow fully into the slot.
4. Place your hand between the device and the strap, and secure the strap that is inserted into the top ring to the attachment point.

7. Trigger Handle

7.1 Contacts

www.m3mobile.net / www.m3mobile.co.kr

Headquarter

Seoul Korea

+82-2574-0037

sales@m3mobile.co.kr

Factory/Service Center

Bucheon Korea

+82-32-623-0037

cs@m3mobile.co.kr

EU Headquarter

Frankfurt Germany

+49-6190-8021829

sales_all@m3mobile.co.kr